


Not Shown: LL-9826 Locking Coupling Assembly

PARTS LIST				PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	LL-9801	RETRIEVING POINT	15	1	LL-9815	PISTON SHAFT SPRING
2	1	LL-9802	ROLL PIN	16	1	LL-9816	PISTON
3	1	LL-9803	SPRING HOUSING	17	1	LL-9817	J SLOT PIN
4	1	LL-9804	MAIN SHAFT	18	1	LL-9818	SLIDE TUBE
5	1	LL-9805	MAIN SPRING	19	1	LL9819	O-RING CARRIER
6	3	LL-9806	LATCH EARS	20	1	LL-9820	LANDING SHOULDER
7	1	LL-9807	LATCH BODY	21	1	LL-9821	BEARING ADAPTOR
8	1	LL-9808	MAIN CROSS PIN	22	2	LL-9822	O-RING
9	1	LL9809	COTTER PIN	23	1	LL-9823	GREASE ZERK
10	1	LL-9810	ROTATION LOCKING DOG	OPTIONAL PARTS			
11	2	LL-9811	ROTATION LOCKING DOG SPRING	25.A	1	LL-9825-A	PIVOT HEAD BASE
12	4	LL-9812	ROLL PIN	25.B	1	LL-9825-B	PIVOT HEAD
13	1	LL9813	ROLL PIN		NOT	LL-9830	9 PIECE PI N KIT
14	1	LL-9814	PISTON SHAFT		SHOWN		



THIS DRAWING CONTAINS PROPRIETARY INFORMATION AND SHALL NOT BE REPRODUCED, COPIED, OR USED AS A BASIS FOR ANY MANUFACTURING WITHOUT PERMISSION FROM NORTHWEST MACHINE WORKS . ALL DRAWINGS MUST BE RETURNED UPON REQUEST.

PROGRAM NO	REV	<b>GENERAL SPECIFICATIONS UNLESS OTHERWISE SPECIFIED</b> RADIUS ALL CORNERS .0313 ANGLES = +/-1° DEBURR ALL SHARP CORNERS				NO:	REVISIONS:	DATE:	DRAWN BY: Paul C	ISSUED 3/17/2011	
								CHECKED BY:	PATENT PROTECTED		
		X	XX	XXX						LL9800 HWL LOCK N LOAD® LATCH HEAD	
		.031	.01	.005						MATERIAL:	
	250	125	63	2318 GRAND PARK DR. GRAND JUNCTION, CO 81505 970-242-1356				DWG NO. LL9800			